

DISINFECTION TUNNEL

Instructions for Use

Triple Action Disinfectant Tunnel: Spray, UV, Wet Carpet



Technical data:

Technical Data for disinfection Tunnel

dimensions

Model-1 : 20x20 frame, 4mm polycarbonate; H: 2.1m, L: 1.2m, L: 1.05m

Model-2 : 20x20 frame, 4mm polycarbonate: H: 2.1m, L: 1.2m, L: 0.72m

Power supply: 220v-240v, 0.5A

UV 15W - 36w

Pressure pump 3-5bar, 1-2l / min - 12v source /

Atomizer 100ml liquid when activating the sensor

Careful!

* It is not recommended to stay in the tunnel, more than 60 seconds with direct exposure to UV rays

** The system includes the container and not the disinfectant solution. It is suitable for any type of disinfectant.

*** For the safety of the user in case of electrical short circuit, it is not recommended to use alcohol + 70% in the spray and pumping system.

Use:

1. Triple Action Disinfection Tunnel.

- It is mobile, and can be placed in any location

2. After placing the unit:

- connect the plug to the 230v socket,

- fill the container with the chosen solution

- inserted the hose in the container!

3. Activation is done using motion sensors, and will spray for a pre-set period from sensor activation. We can advise if you want to change sensor activation times.

4. The control box contains the pressure pump and the power supply.

5. The tunnel contains the spraying system with 5 nozzles, for integral coverage

The disinfectant tunnel does not require other interventions or connections; it is delivered pre-assembled